

2.4GHz Presenter With File Transfer

User's Manual

ABOUT THIS MANUAL

This manual is designed for use with the 2.4GHz Presenter with File Transfer. Information in this document has been carefully checked for accuracy; however, no guarantee is given to the correctness of the contents. The information in this document is subject to change without notice. The manufacturer does not make any representations or warranties (implied or otherwise) regarding the accuracy and completeness of this document and shall in no event be liable for any loss of profit or any commercial damage, including but not limited to special, incidental, consequential, or other damage.

SAFETY INSTRUCTIONS

Always read the safety instructions carefully:

- Keep this User's Manual for future reference
- Keep this equipment away from humidity
- If any of the following situation arises, get the equipment checked by a service technician:
 - The equipment has been dropped and damaged.
 - The equipment has obvious sign of breakage.
 - The equipment has not been working well or you cannot get it to work according to the User's Manual.

COPYRIGHT

This document contains proprietary information protected by copyright. All right are reserved. No part of this manual may be reproduced by any mechanical, electronic or other means, in any form, without prior written permission of the manufacturer.

TRADEMARKS

All trademarks and registered trademarks are the property of their respective owners or companies.

CAUTION : Laser radiation

Do not stare into beam!

Table of Contents

1. Introduction	1
Features.....	1
Package Contents.....	2
System Requirement	2
Software and operation system support.....	2
2. Installation	3
3. Using the presenter	4
4. File Transfer Flash Drive	6
5. Specifications.....	9
6. Regulatory Compliance	10
FCC Conditions	10
CE.....	10
WEEE Information.....	10

1. Introduction

This **2.4 GHz Presenter with File Transfer** will offer you increased control for more effective presentations. Please read this manual to learn valuable information about the proper use and installation.

With this 2.4 GHz Presenter with File Transfer, you don't need to stand beside your computer or have an additional person click the slide for you, nor do you need to aim at the receiver of the remote control.


It is the mixed of RF wireless control of PowerPoint keyboard shortcuts and the laser point. This device enables the user to control presentation slides wirelessly up to 15 meters away indoors, while the laser pointer up to over 15 meters from the target.

2.4 GHz Wireless Presenter embedded File Transfer function. It provides simple USB 2.0 Plug-n-Play functionality in two easy steps – connect a USB port on both PCs and start transferring data. The new GoSuite utility software is already embedded on it and will automatically load onto your system.

Features

- Keys to support power point “next page”, “previous page” bottoms.
- Built-in laser pointer
- Compatible with most presentation applications including Microsoft PowerPoint.
- Up to 15 meters of wireless range.
- Internal flash size is 2G, 4G, 8G or Higher.
- No software required of 2.4GHz Presenter.
- Plug & play
- New GoSuite software application program loads automatically and easy manager/ transfer the data.

2. Installation



3. Using the Presenter

Step 1: Open the battery cover on the back and insert the battery.

Notes on battery

- Do not insert battery into the Mini Presenter in the wrong direction.
- Do not leave dead or exhausted battery in the Mini Presenter.
- If you do not use the Wireless Presenter for a long period of time, remove the battery to avoid possible damage from battery corrosion.
- If the Wireless Presenter does not function correctly or if the operating range becomes reduced, try to replace the battery with new one.

Step 2: Take out the Wireless Dongle and plug it into an available USB port.

Plug the Wireless Dongle into your computer's USB port. You may also use the spare USB port on your keyboard or a USB port on a hub connected to your computer.

You do not need to turn off your computer before connecting or disconnecting a USB device.

The operation system identifies the Wireless Dongle and begins the installation automatically. Please follow the instruction on the screen to complete the installation procedure.

Step 3: The function of the keys


Key	Function
▶	Click to start the slide show / exit the slide show
<	Previous Slide (Page Up)
>	Next Slide (Page Down)
	Laser beam
	On/Off Bottom

4. File Transfer Flash Drive

Installation

On Windows 2000 / XP / Vista

1. Plug in **File Transfer Flash Drive** on your computer first. After the connection, only under Vista operating system will be few pop-up screens appear as below.



You may select **Open folder to view files / Open folder to view files** and directly open the source Disk as above or to use **GO! Suite** and execute the installer program.



Notice for Windows Vista users :

If you encounter a User Account Control dialog box when attempting to install a program, enter an administrator password or click Allow to start the installation.



2. When the **GO! Suite** prompted as below, please click on the **GO! Bridge / Folder Sync / Outlook Sync/ GO! Finder** to use the function that you like.



**Actual strings depend on your operation system. These screen shots are from Windows Vista and might vary slightly for each operation system.*

GO! Suite

1. When using the function of **GO! Finder**, please plug File Transfer Flash Driver into the computer USB port, and follow the steps and then use the file transfer flash drive.
2. When using the function of **GO!Bridge / Folder Sync / Outlook Sync** or when you see the screen prompted as below, please use USB cable to connect two computers as figure and follow the steps then use the file transfer flash drive.



5. Specifications

Programmable Data Rate	Up to 500 Kbps
Compliance	USB1.1 & USB 2.0
Operating Systems	Windows 2000, 2003, XP & Vista Mac OS X v10.4 , 10.5 or later
RF Band	2.4 GHZ
Max Distance	15 meters
Power Supply	1 AAA 1.2V battery
USB RF Dongle	USB Type A Plug; Mini USB
Size (Lx W x H)	128.9 x 39.9 x 30.8 mm
Housing Material	Plastic (ABS)
weight	60g
Operation temperature	10 ~ 40 degree °C
Storage temperature	-10 ~ 80 degree °C
Certification	FCC, CE

* Specification is subject to change without notice

6. Regulatory Compliance

FCC Conditions

This equipment has been tested and found to comply with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference
- (2) This device must accept any interference received. Including interference that may cause undesired operation.

Important! Changes or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment. Use an approved phone set.

CE

This equipment is in compliance with the requirements of the following regulations:
EN 55 022: CLASS B

WEEE Information

For EU (European Union) member users:

According to the WEEE (Waste electrical and electronic equipment) Directive, do not dispose of this product as household waste or commercial waste. Waste electrical and electronic equipment should be appropriately collected and recycled as required by practices established for your country. For information on recycling of this product, please contact your local authorities, your household waste disposal service or the shop where you purchased the product.

